CRJ CHECKLISTS



Item	Desired State	Cheats
SAFETY CHECKS		
Circuit Breakers	Closed	Behind the PF and FO seats, ensure none have popped
Nose Wheel Steering Switch	Off	Left of the PFD for PF and FO
Cargo Air	Off	
Hydraulic Pumps	Off	Overhead Center Front
Landing Gear Lever	Down	Center Console
Flight Spoiler Lever	Retracted	Next to thrust levers
Slats / Flaps Lever	Set	Next to thrust levers
Radar	Off	Pedestal next to seats PF and FO sides
ADG Manual Release	Stowed	Back of Pedestal
Emergency Flap Switch	Normal	Back of Pedestal right side
Battery Master Switch	On	Overhead Left
APU	As Required	Overhead Center, if you're going to immediately start the APU then you don't need external power.
External Power	As Required	EFB
External Air	As Required	EFB
IRS	Nav	Back of Pedestal left side
Emergency Equipment	Checked	
Gear and Safety Pins	On Board	
Airplane Documents	Checked	
Hydraulic 3A Pump	On	Overhead Center Front
FMS Initialization	Complete	Front of Pedestal
CABIN INSPECTION CHECKLIST		
Cabin Inspection	Accomplished	
Chocks	In	
Walkaround Inspection	Accomplished	
ORIGINATING CHECKLIST		
Crew Oxygene and Masks (first flight only)	Checked	Next to seat on the outside
Audio Warning Panel	Checked	Next to seat on the outside
Electrical Power Panel	Checked	Overhead
Fire Detection Test (first flight only)	Complete	Overhead
External Lights Panel	Checked	Overhead
Fuel Panel	Checked	Behind the FO seat at the top

Bleed Air Panel Checked Overhead
APU Panel Checked Overhead
Start Panel Checked Overhead
Hydraulic Panel Tested and Set Overhead
ELT Switch Arm / Reset Overhead

Cabin Pressure Panel Checked Overhead top right

Air Conditioning Panel Checked Overhead

Anti-Ice Panel Checked Overhead right

WIndshield Heat Low Overhead right

Emer Lts Switch Armed Overhead

Standby Compass Checked Windshield

Nosewheel Steering Switch Off Next to PFD on the left Clocks Set Next to PFD on the left Instrument Panels Checked PF and FO panels

Upper Pedestal Checked

CVR Tested In front of you behind the yoke

Thrust Lever Quadrant Checked

Avionics / Radio Tuning Panel Checked FMS and pedestal left side

Trims Checked Displayed on right CAS - run the aileron and rudder trims to each of their extremities

Yaw Damper Engaged Pedestal center

Source Select Panel Norm Left of PFD (this is usually set by default)

BEFORE START CHECKLISTS

Passenger Signs On Overhead right

Landing Elevation Set Overhead top right (elevation displayed on right-hand CAS - I generally pop out this screen while turning the knob)

Altimeters Set Left of PF PFD and right of FO PFD, secondary is right of your ND

FMS Set Front of pedestal

IRS Aligned / Nav Back of pedestal left side

Radios and Nav Aids Set FMS and Pedestal

Take-Off Briefing Complete

ENGINE START CHECKLIST

Personal Electronic Devices Off Turn off your cell phones (also make sure the cabin no smoko sign is on)

APU On Overhead

Flectronics Checked

Take-Off Data Set In FMS (or transferred from EFB)

Doors Closed and Locked EFB for outer doors, pedestal for cockpit door

Beacon On Overhead

Fuel Pumps and Quantity

On, XX kgs

Overhead and CAS

Anti-Skid Armed Pedestal between FMS and Gear level (this defaults to armed)

Hydraulic PumpsAuto / OnOverheadParking BrakeOffPedestalExternal Power and AirRemovedEFB

Chocks Removed Pushback Begin

Engine 2 Start Button Overhead

Engine 1 Start Button overhead once Engine 2 is stable (watch N1 on the left CAS)

Throttle 1 to Idle Move throttle for engine 1 from Shut Off to Idle when N2 gets to 20.0 on the left CAS

AFTER START CHECKLIST

Generators Overhead Auto Overhead Electrics Checked **Bleed Valves** Overhead Auto **Packs** On Overhead APU On / Off Overhead Cargo Air As Required Overhead right Anti-Ice On / Off Overhead Probe Heat On Overhead

Nosewheel Steering Armed Left of PF PFD - DO THIS AFTER TUG DISCONNECTS

DURING TAXI CHECKLIST

Slats / Flaps XX degrees indicating Pedestal (indicated on left CAS)

Flight Controls Checked

Trims Green and XX units Indicated on right CAS
Thrust Reversers Armed Pedestal near throttle

Anti-Ice As Required Overhead

Flight Instruments Checked

Taxi Lights On Overhead

Brake Temp Checked Indicated on right CAS

BEFORE TAKE-OFF CHECKLIST

Lights and Strobes On Overhead Fuel XFlow Manual Overhead

Flight Attendant Advised Pedestal button (just for flavour)

Runway Checked vs FMS Checked Visually confirm the runway number vs what's in the FMS

Transponder / TCAS On / Set Pedestal

Radar / Terrain Display On / Set Left of PF PFD and right of FO PFD

Altimeters Checked Last verification of baro

CAS Checked

AFTER TAKE-OFF / CLIMB CHECKLIST

Gear Up On positive rate of climb

Flaps Up When you have enough speed (I think this is indicated on the speed tape on the PFD)

Fuel XFlow Auto Overhead

Climb Power Set Reduce from TOGA to Climb

Bleeds Auto Overhead (this is their default state)

Thrust Reversers Off Pedestal

CAS Checked

Lights Checked Switch them off as necessary
Altimeters Set Switched to STD after transition alt.

DESCENT CHECKLIST

Landing Elevation Set Overhead (indicated on right CAS)

Seatbelts On

Fuel Checked Indicated on right CAS

TCAS Checked

Radar On (WX) Pedestal near seat on PF and FO sides

CAS Checked

Landing Data Set PFD (transferrable from EFB)

Altimeters Set Baro set correctly after crossing transition altitude

External Lights Set As required

Approach Briefing Complete

APPROACH CHECKLIST

APU On / Off Overhead

Transponder / Radar Standby / Off Pedestal, left side by seat Flaps Up / Zero Indicated on left CAS

Lights and Strobes Set Overhead Probes Off Overhead

PARKING CHECKLIST

Parking Brake On Pedestal back side

Seat Belts Off Overhead

Thrust Levers Shutoff Throttle quadrant

Anti-Ice Off Overhead Fuel Pumps Off Overhead

External Power	As Required	Chocks needed if you determine this is required.
External Air	As Required	Chocks needed if you determine this is required.
Thrust Reversers	Off	Pedestal
Cargo Air	Off	Overhead
Recirculating Fan	Off	Overhead
Beacon	Off	Overhead
Nosewheel Steering	Off	Left of PF PFD

SECURING THE AIRCRAFT CHECKLIST

Chocks and Breaks	In and Off	EFB
IRS	Off	Pedestal
Emer Lts Switch	Off	Overhead
Anti-Ice	Off	Overhead
Hydraulic Pumps	Off	Overhead
External Lights Switches	Off	Overhead
APU	Off	Overhead
External Power	Disconnected	EFB
External Air	Disconnected	EFB
Battery Master	Off	Overhead
Cockpit Lights	Off	Various